

wallrock[®]

WWW.ERFURTMAY.COM



**TRANSFORMING THE ROUGH
INTO THE SMOOTH**

wallrock

CHOOSE YOUR IDEAL WALLROCK FIBRELINER FINISH



NEW WALLROCK FIBRELINER SMOOTH 150 FOR A SMOOTHER FINISH

WALLROCK FIBRELINER ORIGINAL 150



TIP: FIBRELINER ORIGINAL AND SMOOTH ARE AVAILABLE IN 55, 75, 100 CM WIDTHS FOR FASTER MORE EFFICIENT PAPER HANGING, REMEMBER DIFFERENT WIDTH ROLLS CAN BE USED TOGETHER TO LIMIT WASTAGE. [CLICK HERE TO USE OUR FREE CALCULATOR](#)



SELECT YOUR ADHESIVE



TIP: ALWAYS USE A GOOD QUALITY READY MIXED ADHESIVE TO ENSURE RELIABLE BONDING AND EASY HANGING. ANY GOOD QUALITY READY MIXED ADHESIVE CAN BE USED.

wallrock

**ENSURE THAT BASE SURFACES
ARE CLEAN, DRY, FIRM AND FREE
FROM ANY LOOSE OR FLAKING
MATERIAL**

✓ **TIP: USE A 120 GRIT SANDPAPER TO
SUITABLY CLEAN UP THE SURFACE**

✓ **TIP: SOME SURFACES ESPECIALLY NEW
PLASTER MAY NEED TO BE SIZED BEFORE
HANGING ANY WALLCOVERING**

wallrock

TOOLS FOR THE JOB

STRAIGHT EDGE / SPIRIT LEVEL



TAPE MEASURE/RULER



STRING LINE



DECORATORS SPONGE



SNAP BLADE



MEDIUM BRUSH



WALLPAPER SMOOTHER/FORMER



PENCIL



MEDIUM PILE ROLLER AND TRAY



**USE STRING LINE TO ENSURE
FIRST DROP IS VERTICAL.**



wallock

**ALTERNATIVELY USE A SPIRIT
LEVEL AND PENCIL TO MARK
A VERTICAL LINE**

wallock

USE A BRUSH TO LOAD ANY FINE CRACKS WITH POWER ADHESIVE



✓ TIP: ANY SIGNIFICANT CRACKS SHOULD
BE FILLED WITH AN APPROPRIATE FILLER



wallrock

✓ TIP: PASTE OVER THE LINE TO ENSURE ALL THE SURFACE IS COVERED, USE A BRUSH TO APPLY ADHESIVE WHERE THE ROLLER CANNOT REACH



USE THE ROLLER TO APPLY AN EVEN LAYER OF ADHESIVE

walrock

FOR SPEED HANG FIBRELINER STRAIGHT FROM THE ROLL

✓ TIP: WALLROCK FIBRELINER IS PASTE THE WALL WHICH MEANS NO SOAKING TIME OR PASTING TABLE IS REQUIRED

wallrock

**APPLY FIRST LENGTH USING THE
LINE AS A GUIDE**



✓ **TIP: MAKE SURE THE FIBRELINER IS
FLUSH TO THE LINE ACROSS THE
ENTIRE DROP**

wallrock

✓ TIP: WORK FROM THE CENTRE OF THE DROP WHEN SMOOTHING OUT



USE PAPER SMOOTHER / FORMER TO ENSURE PAPER IS FLAT AND SMOOTH

wallrock



TIP: USE THE WALLPAPER SMOOTHER TO SMOOTH OUT BOTH DROPS AND ENSURE SURFACE IS FLAT

BUTT JOINT THE FIBRELINER CAREFULLY FOR A GOOD FINISH

wallrock

✓ TIP: ALTERNATIVELY THE TOP AND BOTTOM CAN BE MARKED WITH A PENCIL AND TRIMMED USING GOOD QUALITY DECORATING SCISSORS



USE A SHARP KNIFE WITH A PAPER SMOOTHER FORMER TO TRIM TOP AND BOTTOM

wallrock



**NOW YOU HAVE AN IDEAL SURFACE FOR
PAINT OR DECORATIVE PAPER**

✓ **TIP: ALLOW FIBRELINER TO DRY THOROUGHLY BEFORE APPLYING PAINT OR OVERHANGING WITH ANOTHER WALLCOVERING (NORMALLY 24 HOURS IS SUFFICIENT)**

wallock

TRANSFORMING THE ROUGH INTO THE SMOOTH

wallrock

A HIGHLY VERSATILE PROBLEM SOLVER



wallrock[®]

FOR FULL DETAILS AND PRODUCT INFORMATION
VISIT US ONLINE